

# Instructions for Modifications to Hobby Boss Iguana 1/35 scale

Most parts can be installed as seen in picture but some will need some modifications to the kit. These are explained here.

## Lower hull modification HB Part Lower Hull

- Line part J15 to lower front hull and mark. Cut out this area so part J15 fit in the hole.
- On part J15, remove the ice grousers.
- After completion of step 2, patch holes on side hull.
- Add the mine protection plate not called for in instructions

## Top plate of lower hull modifications

- Remove mount point for the barrel holder
- Remove bar on left side of pick
- Remove shovel points
- Remove left access point in front of left air intake
- Fill all holes not being used.
- Remove material on right rear starting at the batter access point toward rear using the replacement auxiliary generator as a guide. Install the auxiliary generator making sure it is lined up to fit lower hull.
- Using the access panel on the left side that sits in front of the vent, remove material so it fits flush.
- Remove both front fenders in front of the mount bolts and add new ones right an left triangle part on side on inside
- Install new drivers hatch instead of part J9

## Step 7 in instructions

- Remove stop part on part K19
- Remove ice grousers on J21
- Don to install Part F5. Fill holes
- Add pictured parts (picture 1)

## Step 8 in instructions

- Remove front step on part C1 and C2. From the rear, remove material and plate split in front of 5<sup>th</sup> plate on side skirts.
- Do not install F2 on the left side

- If using the folded rear mud flaps, remove the mud flap under the connection rod and secure new ones.
- Remove rear grill parts below the 11<sup>th</sup> for the rear tail lights. Cut inward to fit. There should be a small amount of grill on the inside of the tail lights.
- After installing the front blade, add the locking pin parts on the right angle strap and the top of the hull on the right side of the extra track links.
- There is a hole in the marker rod springs that sit on the right and left side of the blade. Add a 28mm long rod and drill a hole to help secure it.
- Remove the rear most panel box on front supplemental armor for both side. Secure lining up the front then add the small 1mm by 2mm boxes at the mount point. Watch the alignment

#### Step 9 in instructions

- Do not install U63. The camera site in the underside of rear boom.
- Do not install tow cable as indicated. It runs along both upper side from the full cap to the rear.
- Install parts as seen in pictures

#### Step 10 in instructions

- Cut notch out of part U41 after installation and glue has dried for the middle tail light
- Remove all old braces on parts U49+J5 and U42+J4 so they are smooth. Save the top 2 parts. They will be reglued on closer to the top. The right side one will be 1 mm shorter then the left one.
- Do not install parts J23, F28, J19, U73 & U74, F13(12), U77,J16 ,J17 ,F29, U35 or F14.
- Replace with resin parts

#### Step 11 in instructions

- Do not use model deployment camera. Smooth mount point as it sits further back.
- After assembly, add resin parts

#### Step 12 and 13 in instructions

- Do not use parts F32, U9 & U8
- Add resin parts in 12 threw 14 as pictured

#### Step 15

- Only add part K5
- Use either the up or down mirrors cutting downward rod to fit







































